

CELLA BERLIN

**Produktreihe
2018**

1101_10_010 Brotteller Ø 16 cm




1102_10_010 Dessertteller Ø 22 cm




1103_10_010 Bistroteller Ø 25 cm



1104_10_010 Speiseteller schmaler Rand Ø 25,5 cm



1105_10_010 Speiseteller Ø 28,5 cm



1106_10_010 Platzteller Ø 32,5 cm



1107_10_010 Pizzateller Ø 34 cm



1108_10_010 Teller tief Ø 23 cm



1109_10_010 Teller tief Ø 25,5 cm



1110_10_010 Gourmet Teller Ø 27,5 cm



2106_10_010 Gourmet Teller Ø 30,5 cm



1201_10_010 Olivenschale 15 x 6 cm



1202_10_010 Coupeschale oval 30 x 10,5 cm



1203_10_010 Hors d'Œuvre Schale 30,5 x 14 cm



1204_10_010 Tablett oval 29,5 x 21 cm



1205_10_010 Fischplatte oval 32 x 24 cm



1206_10_010 Platte oval 38 x 19 cm



1207_10_010 Platte oval 46 x 22,5 cm



1301_10_010 Coupeteller rechteckig 27 x 16 cm



2101_10_910 Schälchen mit Deckel Ø 11,5 cm



2102_10_010 Schale Ø 12 cm



2103_10_010 Dessert Schale konisch Ø 15 cm



2104_10_010 Müslischale konisch Ø 17 cm



2105_10_010 Schälchen konisch Ø 21 cm



2107_10_010 Schale konisch Ø 26 cm



2108_10_010 Schale konisch Ø 20 cm



2109_10_010 Dip Schälchen Ø 8 cm



2110_10_010 Schale Ø 19 cm



2201_10_010 Schale Oval 17 x 12 cm



2301_10_010 Schale rechteckig 27 x 16 cm



2401_10_010 Schälchen quadratisch 8,5 x 8,5 cm



3107_10_010 Espressotasse Obere 0,06 l

3121_10_010 Untertasse Ø 11 cm



3101_10_010 Espressotasse Obere 0,09 l



3102_10_010 Consommé Tasse 0,39 l



3103_10_010 Teetasse Obere 0,3 l



3104_10_010 Tasse Obere 0,19 l

3123_10_010 Untere Ø 15,5 cm



3105_10_010 Tasse Obere 0,31 l

3122_10_010 Untertasse Ø 16,5 cm



3106_10_010 Becher mit Henkel 0,4 l



3121_10_010 Untertasse Ø 11 cm



3123_10_010 Untere Ø 15,5 cm



3122_10_010 Untere Ø 16,5 cm



4102_10_010 Kaffeekanne / Teekanne 0,72 l



4101_10_010 Kaffeekanne / Teekanne 1,1 l



4103_10_010 Gießer 0,06 l



4104_10_010 Gießer 0,15 l



4105_10_010 Gießer 0,5 l



5101_10_010 Eierbecher Ø 11 cm



5102_10_010 Pfefferstreuer Ø 5 cm



5103_10_010 Salzstreuer Ø 5 cm



5104_10_010 Kerzenständer Ø 8 cm



5105_10_010 Vase Ø 9 cm



5106_10_010 Teelicht Ø 10,5 cm



5107_10_010 Cloche Ø 24 cm



5108_10_010 Centerpiece Ø 35 cm



5109_10_010 Zuckerdose mit Deckel Ø 11 cm



5111_10_010 Terrine 2,5 l



5301_10_010 Cloche rechteckig 28 x 17 cm

